

How to measure for Vertical Blinds

Measuring for Vertical Blinds couldn't be more straightforward. Grab yourself a metal tape measure, a pencil, a piece of paper, and you're good to go.

Standard Window - Recess Fitting Instructions

Step 1: Measure the width of your recess in three locations. The top, middle and bottom. Record the smallest measurement.

Step 2: Measure the drop of your recess in three locations. The left, middle and right. Record the smallest measurement.

Step 3: Use the smallest measurement for the width and the drop.

Hint: Check your window recess for any obstructions such as tiles or picture rails. If you do have an obstruction, make sure you measure off this point. A deduction of 5mm will be made to the overall width to ensure an easy, yet snug fit. A deduction of 10mm will make to the overall drop to ensure no dragging along the window sill. If you order a recess size, we will supply top fix brackets, allowing you to install the blind into the top of the window recess.



Blind Size Measuring Instructions

Step 1: Measure the outside of your window recess from one side to the other, from the point you want the edge of the blind to start to the other.

Step 2: Measure the outside of your window recess from the top to the bottom, from the height at which you want the headrail positioned, down to the point you want the bottom of the veins to finish.

Hint: We recommend a minimum of a 70mm overlap past the window recess, that's 35mm on each side. This ensures total coverage of the recess. Your new blind will be made to your exact measurements with no deductions to the width, or the drop. If you order as blind size, we will supply face fix brackets, allowing you to install the blind onto the face of the wall around your window reveal.